

**Call 01 Installing Median Cable Barriers, known as Federal Aid Project Nos. HSIP-0020-01(214), HSIP-0020-01(215), and HSIP-0020-02(086) / 106780301, 302, & 303 in Hinds, Rankin, and Lauderdale Counties.**

Q1. Is the Excess Excavation item to only include the removal of the older shoulder materials?  
Or is this for the entire project including the vegetation pad?

A1. The excess excavation quantity will be measured from the edge of pavement to the front edge of the vegetation control pad.

Q2. What is the distance of the cable barrier from the edge of the travel lane?

A2. The distance will vary with field conditions.